







Windows 8, 8 and 10

WR1 USB Driver

Step	Action	Display
1	<p>To disable driver signature verification, we're going to need to get into the Troubleshooting options from the boot manager.</p> <ol style="list-style-type: none"> Navigate to where you shut down your PC Hold down the "SHIFT key" while you click the "Restart" button and continue holding the shift key until "Choose an option" appears (see step 2) 	
2	<ol style="list-style-type: none"> Once your computer has rebooted you will be able to choose the "Troubleshoot" option 	
3	<ol style="list-style-type: none"> Then head into "Advanced options". 	




Windows 8 and 10

WR1 USB Driver

Step	Action	Display
4	a) Then "Startup Settings"	 <p>Advanced options</p> <p>System Restore Use a restore point recorded on your PC to restore Windows</p> <p>Startup Settings Change Windows startup behavior</p> <p>Startup Repair Fix problems that keep Windows from loading</p>
5	<p>Since we are modifying boot time configuration settings, you will need to restart your Computer one last time.</p> <p>a) Select "Restart"</p>	 <p>Restart to change Windows options such as:</p> <ul style="list-style-type: none"> • Enable low-resolution video mode • Enable debugging mode • Enable boot logging • Enable Safe Mode • Disable driver signature enforcement • Disable early-launch anti-malware protection • Disable automatic restart on system failure <p>Restart</p>
6	a) Select "Disable driver signature enforcement". by pressing the #7 key on your keyboard.	 <p>Startup Settings</p> <p>Press a number to choose from the options below:</p> <p>Use number keys or functions keys F1-F9.</p> <ol style="list-style-type: none"> 1) Enable debugging 2) Enable boot logging 3) Enable low-resolution video 4) Enable Safe Mode 5) Enable Safe Mode with Networking 6) Enable Safe Mode with Command Prompt 7) Disable driver signature enforcement 8) Disable early launch anti-malware protection 9) Disable automatic restart after failure




Windows 8, 8.1 and 10

WR1 USB Driver

Step	Action	Display
7	a) Log In to your computer as normal	
8	a) Power on Your WR1 and connect it to your PC with the USB to Mini USB power cable b) Download and save to your PC the "linux_cdc_seial.inf" driver	
9	a) Right Click on the Windows Start icon and select "Device Manager"	



Windows 8 and 10

WR1 USB Driver

Step	Action	Display
10	a) Right Click on the “CDC Serial icon” located under “Other Devices” And Select “Update Driver”	
11	a) Select “Browse my computer for driver software”	
12	a) Browse to the folder where you saved the downloaded driver in step 8b. b) Press “Next”.	

Windows 8 and 10

WR1 USB Driver

Step	Action	Display
13	a) If you get a warning about the driver publisher select "Install this driver software anyway"	
14	a) You should get a window saying that the driver was successfully installed b) Exit to the "Main Windows Desktop" c) Restart your PC. This will restore the changes we made in steps 1-6 and save your new USB Driver update	
15	<p>Please contact either your local dealer or Champion Instruments at 770-243-3254 with any questions.</p> <p>www.championinstruments.com</p>	